



Formula ID 537 Compound M66-99 Cure: P Color: B
Urethane Type: Polyester

Application: 65 Shore A, Black, Static Conductive Millathane® 66/66R Compound

Millathane® 66/66R*	100.00	Durometer, Shore A	65	
Stearic Acid	0.25	Durometer, Shore D		
Struktol WB-222	0.50	Durometer, Asker C		
XC-72 black	27.00	25% Modulus, psi		MPa
DBEEA (TP-95)	10.00	50% Modulus, psi		MPa
Millstab P*	1.50	100% Modulus, psi	476	3.3 MPa
Varox DBPH-50	4.00	200% Modulus, psi	1289	8.9 MPa
TAC	1.50	300% Modulus, psi	2108	14.5 MPa
		Tensile Strength, psi	3487	24.0 MPa
		Elongation, %	454	
		Tear Die C, lb/in.		kN/m
		Tear Die B, lb/in.		kN/m
		Tear Die T, lb/in.		kN/m
		Specific Gravity, g/cc		
		CureTime, minutes	10	
		Cure Temp°F	330	166 °C
		Mooney Viscosity, ML4/100°C		
		Heat Aging <input type="text"/> Hrs at <input type="text"/> °C		
		Hardness Change, pts.		
		Tensile Change, %		
		Elongation Change, %		
		Fluid Aging <input type="text"/> Hrs at <input type="text"/> °C		
		Hardness Change, pts.		
		Tensile Change, %		
		Elongation Change, %		
		Volume Change, %		
		Surface Resistivity, ohm/cm ²	5.0E+06	
		Volume Resistivity, ohm-cm		
		UL 94 Rating:		
		Total	144.75	
Brittle Point, °C	<input type="text"/>			
TR10, °C (ASTM D1329)	<input type="text"/>			
Bashore Resilience, %	<input type="text"/>			
DIN Abrasion, mm ³ loss	<input type="text"/>			
Compression Set 22h/70°C, %	<input type="text"/>			
Compression Set 70h/70°C, %	<input type="text"/>			
Compression Set 22h/100°C, %	<input type="text"/>			
Compression Set 70h/100°C, %	<input type="text"/>			
Compression Set 22h/125°C, %	<input type="text"/>			
Compression Set 22h/150°C, %	<input type="text"/>			
Compression Set, Other conditions:	<input type="text"/>			
	<input type="text"/> h/ <input type="text"/> °C, %			

Other Tests and Info: *Millathane 66 Premilled, at 101.5 parts, can replace the Millathane 66 (Virgin) and Millstab P, as it contains 1.5 phr of Millstab P, a hydrolysis stabilizer. Additional Millstab P (or Stabaxol P) can be added for increased protection against hydrolysis.

10/1/2020

The recommendations for the use of our products are based on tests believed to be reliable. However, we do not guarantee the results to be obtained by others under different conditions nor do we guarantee that this or other formulas will work in a specific application. Nothing in this literature is intended as a recommendation to use our products so as to infringe on any patent. Millstab™ is a trademark, and Millathane® and Thanecure® are registered trademarks of TSE Industries, Inc. All other brand names and product names referenced are trademarks, registered trademarks or trade names of their respective holders.